INE-5MS-2100

RUGGED INDUSTRIAL UNMANAGED SWITCH

Unmanaged, 5*10/100Base-T(X) RJ45, dual power supply 9~60VDC, Optional DIN Rail Mounting





Data Conversion Experts

INDUSTRIAL PROVEN RELIABILTY








PRODUCT OVERVIEW

The INE-5MS-2100 is a rugged industrial grade slim unmanaged 10/100M Ethernet switch with 5 10/100M RJ45 ports, a 12/24/48VDC (9-60VDC) redundant power input, and an attached removeable DIN Rail mount.

POWER SUPPLY CONNECTION




The INE-5MS-2100 utilizes a 4-pin terminal block as a power input with a voltage range of 12/24/48VDC (9-60VDC). The power input can support either one single power supply, or two separate power supplies at the same time for redundancy. When the power input uses the redundant power supply, P1 is the

primary power input and P2 is the secondary power input. The terminal block also supports anti-reverse connection so that if the power supply is connected backwards, the device won't get powered or become damaged.

DIP SWITCH SETTINGS

No.	Definition	Operation
1	Loop Detection	Set the switch to the ON position to enable the loop detection function.
2	Storm Suppression	Set the switch to the ON position to enable the storm suppression function.
3	VLAN	Set the switch to the ON position to set port 1 as the uplink port and ports 2-5 as the downlinks. Each downlink port is isolated from each other.
4	Flow Control	Set the switch to the ON position to enable the flow control function.

PANEL DESIGN



- 1. Power Input Terminal Block
- DIP Switch
- 3. Grounding Screw
- 4. Removeable DIN Rail Mount
- 5. N/A
- 6. Ethernet Port LED Indicators
- 7. Running LED Indicator (RUN)
- 8. Power LED Indicator
- 9. Fthernet Ports





Jeddy Ventures Limited Liability Company 2400 Belmar Blvd, Unit B-15

Wall Township, NJ 07719 PHONE: 1 (877) 218-7964 FAX: 1 (732) 7490-3598

EMAIL: sales@serialcomm.com

SITE: SerialComm.com



Certified to ISO 9001:2015



REVISION: 1.1

INE-5MS-2100

RUGGED INDUSTRIAL UNMANAGED SWITCH

Unmanaged, 5*10/100Base-T(X) RJ45, dual power supply 9~60VDC, **Optional DIN Rail Mounting**





Data Conversion Experts

INDUSTRIAL PROVEN RELIABILTY







SPECIFICATIONS

SWITCH PROPERTIES		
INTERFACE PROPERTIES		
half		
е		
3:		
MECHANICAL PROPERTIES		

POWER REQUIREMENTS			
OPERATION VOLTAGE:	9-60VDC, Redundant Dual Inputs		
CONNECTION:	1x Removable 4-Contact Terminal Block		
POWER	No-load: 0.2W at 12VDC		
CONSUMPTION	Full-load: 0.8W at 12VDC		
PROTECTION:	Reverse Polarity Protected		
ENVIRONMENT PROPERTIES			
OPERATING TEMP.:	-40°C - 75°C (-40°F - 167°F)		
STORAGE TEMP.:	-40°C - 85°C (40°F - 185°F)		
HUMIDITY:	5% - 95%, (No Condensation)		
REGULATORY APPROVALS			
EMI:	FCC Part 15 Subpart B Class A CE EN 55032 Class A		
FREE FALL:	IEC 60068-2-32		
SHOCK:	IEC 60068-2-27		
VIBRATION:	IEC 60068-2-6		
GREEN:	RoHS Compliant		
MTBF:	444,426 Hours		
WARRANTY:	5 Year Replacement		



MOUNTS: DIN-Rail Mounting

Jeddy Ventures Limited Liability Company 2400 Belmar Blvd, Unit B-15

Wall Township, NJ 07719 PHONE: 1 (877) 218-7964 FAX: 1 (732) 7490-3598

EMAIL: sales@serialcomm.com

SITE: SerialComm.com



Certified to ISO 9001:2015



INE-5MS-2100

RUGGED INDUSTRIAL UNMANAGED SWITCH

Unmanaged, 5*10/100Base-T(X) RJ45, dual power supply 9~60VDC, Optional DIN Rail Mounting





Data Conversion Experts

INDUSTRIAL PROVEN RELIABILTY








DIMENSIONS


Units: mm





DIN RAIL MOUNTING

The INE-5MS-2100 includes a removable standard 35mm Din Rail mount which is compatible with most DIN Rail racks. Mounting steps are as follows:



- Step 1 Power off the Ethernet switch.
- Step 2 Check that the DIN Rail mount is firmly installed on the Ethernet switch.
- Step 3 Insert the bottom of the DIN Rail mount (the end with the spring supports) into the bottom of the DIN Rail on the rack
- Step 4 Tilt and push the Ethernet switch forward so that the rest of the mount clips onto the rail.
- Step 5 Confirm that the Ethernet switch is securely mounted.

DIN RAIL REMOVAL

- Step 1 Power off the ethernet switch.
- Step 2 Slightly tilt the device downwards to shift out the top of the DIN Rail from the DIN Rail mount.
- Step 3 The Ethernet switch can now be removed from the rail.



Jeddy Ventures Limited Liability Company 2400 Belmar Blvd, Unit B-15

Wall Township, NJ 07719 PHONE: 1 (877) 218-7964 FAX: 1 (732) 7490-3598

EMAIL: sales@serialcomm.com

SITE: SerialComm.com



Certified to ISO 9001:2015



Visit Our Website

REVISION: 1.1